

**GGA**

*Hohenleipisch*

**Radioprogramme**

Ausgangsfrequenz		Sender					
1	87.00 MHz						
2	87.50 MHz	R.S.2					
3	88.00 MHz	RSA					
4	88.50 MHz	Harmony. FM					
5	89.00 MHz						
6	89.50 MHz	Schlager Radio					
7	90.00 MHz	MDR 1 Sachsen					
8	90.50 MHz	NRJ - Sachsen					
9	91.00 MHz	PSR					
10	91.50 MHz	BB - Radio					
11	92.00 MHz	Antenne Brandenburg					
12	92.50 MHz	Radio Fritz					
13	93.00 MHz	104 Punkt 6 RTL					
14	93.50 MHz	MDR - Jump					
15	94.00 MHz	Hitradio RTL Sachsen					
16	94.50 MHz						
17	95.00 MHz	103 Punkt 5 Dresden					
18	95.50 MHz	Berliner Rundfunk					
19	96.00 MHz	Radio 88.8					
20	96.50 MHz	Sunshine Live					
21	97.00 MHz	Antenne Bayern					
22	97.50 MHz	Rock Antenne					
23	98.00 MHz	MDR Sputnik					
24	98.50 MHz	Kultur Radio RBB					
25	99.00 MHz	Radio Paloma					
26	99.50 MHz	NDR 1 Radio MV					
27	100.00 MHz						
28	100.50 MHz	Deutschlandfunk					
29							

**Änderungen vorbehalten**